Safety regulations

ADMIRAL Couplers can only be installed or used by competent and/or qualified personnel.

Before using a Coupler you should inspect them visually for any damage. If the coupler is damaged you should be taking it out of service and return it to your local ADMIRAL dealer for inspection.

ADMIRAL Coupler RIHAHCA41 is designed to specifically attach to round tubes of ø 48-51mm and is forbidden to be used in falsework structures.

During installation of the Coupler you must take care not to overtighten the wing nut or wing handle. This to prevent damage to the tube and/or the Clamp/Coupler. If you use only one wing nut or wing handle, it is preferred to only hand tighten it. When you use an additional nut, below the wing nut or wing handle, follow this torque setting: Max. 22-25 N-m.

ADMIRAL Coupler RIHAHCA41 comes with an indicated WLL of 200kg. This WLL may not be exceeded or any other max. load given as instructed during installation.

Couplers that are being used in combination with accessories, should never exceed the max. load of the used accessory.

/ WARNING

Always make sure you double lock the ADMIRAL Couplers, with e.g. two nuts.







A product of ADMIRAL

Josink Kolkweg 10, 7545 PR Enschede The Netherlands, +31 534 301 201



USER MANUAL



Half coupler 48-51mm 30mm BK





www.admiralstaging.com

Half coupler



Ø 32 - 35mm WLL 75kg



Ø 48 - 50mm WLL 100kg



Ø 48 - 51mm WLL 200kg



Ø 48 - 51mm WLL 200kg



Ø 48 - 51mm WLL 500kg



Ø 48 - 51mm WLL 750kg

Half coupler with lifting eye



Ø 48 - 51mm WLL 200kg

Swiffel coupler

Ø 48 - 50mm WLL 100kg





Ø 48 - 51mm WLL 500kg

ADMIRAL CLAMPS AND COUPLERS

Admiral supplies a vast array of clamps and couplers from aluminum half couplers to swivel couplers with a WLL up to 750kg.

Quick coupler



C-clamp

Ø 48 - 50mm
23cm/40cm/60cm

Selflock coupler



Ø 48 - 51mm WLL 250kg



G-clamp



G-clamp straight







